


	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	
A	<div><h1>SHZ 04</h1><p>Diagram illustrating the SHZ 04 power supply system components and connections:</p><ul style="list-style-type: none"><li><b>PSE MODULE</b>: Includes terminals L, N, PE, BAT+, BAT-, -Vo, +Vo, and PSU. A transformer T 3,15A 250V is connected to the L and N terminals.</li><li><b>PANEL EX 3001</b>: Includes a PSU Comm. SUPPLY section with terminals 4 and 2.</li><li><b>Battery</b>: 2x12V/7.2Ah.</li><li><b>Switch</b>: ROZVADĚČ SHZ R01.</li><li><b>Component</b>: WL206 CYKY 3x1,5.</li></ul></div>																			
B																				
C																				
D																				
E																				
F																				
G																				
H																				
CH																				
I																				
J																				
K																				
L																				
M																				



	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	
A	SHZ 04																			A
B																				B
C																				C
D																				D
E	E																			
F	F																			
G	G																			
H	H																			
CH	CH																			
I	I																			
J	J																			
K	K																			
L	L																			
M	M																			