



H30	WCKET GATES SAFETY DISTRIBUTOR
H36	WATER/OIL SEPARATOR WIRING BOX
I20	DRAINAGE, WIRING BOX
I21	LUBRICATION WIRING BOX
I21	TURBINE WIRING BOX
I23	TURNING SYSTEM OIL TANK WIRING BOX
H19	TURBINE BEARING LUBRICATION PRESSURE RELIEF VALVE
H18	TURBINE BEARING LUBRICATION PRESSURE RELIEF VALVE
H17	RUNNER BLADES OPEN LOCK PRESSURE PRESSURE SWITCH
H16	RUNNER BLADES CLOSE LOCK PRESSURE RELIEF VALVE
H15	RUNNER BLADES ACCUMULATOR PRESSURE RELIEF VALVE
H14	RUNNER BLADES MAIN PUMP STOP PRESSURE PRESSURE SWITCH
H13	WCKET GATES ACCUMULATOR PRESSURE RELIEF VALVE
H12	WCKET GATES RELIEF VALVE
H11	RUNNER BLADES ACCUMULATOR LOAD VALVE
H10	WCKET GATES ACCUMULATOR LOAD VALVE
H5	TURBINE SHIP SEAL TEMPERATURE PROBE
H2	RUNNER BLADES ACCUMULATOR LOAD VALVE
H1	WCKET GATES ACCUMULATOR LOAD VALVE
M9	WATER/OIL SEPARATOR DRAINAGE W/ WATER PUMP (SPARE PUMP)
M9	WATER/OIL SEPARATOR DRAINAGE W/ WATER PUMP (MAIN PUMP)
M8	TURBINE DRAINAGE W/ WATER PUMP (SPARE PUMP)
M7	TURBINE DRAINAGE W/ WATER PUMP (MAIN PUMP)
M5	LUBRICATION SYSTEM COOLER MOTOR DRIVEN FAN
M4	TURBINE BEARING PRESSURE OIL PUMP
M3	TURBINE BEARING PRESSURE OIL PUMP
M2	GOVERNING SYSTEM MOTOR DRIVEN OIL PUMP (SPARE PUMP)
M1	GOVERNING SYSTEM MOTOR DRIVEN OIL PUMP (MAIN PUMP)
E50	RUNNER BLADES ACCUMULATOR ISOLATION VALVE ELECTRICAL DISTRIBUTOR
E50	WCKET GATES ACCUMULATOR ISOLATION VALVE ELECTRICAL DISTRIBUTOR
E49	RUNNER BLADES PROPORTIONAL ELECTRICAL DISTRIBUTOR
E15	BRAKE APPLICATION ELECTRICAL DISTRIBUTOR
E11	WCKET GATES SAFETY ELECTRICAL DISTRIBUTOR
E10	WCKET GATES PROPORTIONAL ELECTRICAL DISTRIBUTOR
C163	WATER/OIL SEPARATOR VERY HIGH WATER LEVEL SWITCH (TRIPP)
C162	WATER/OIL SEPARATOR MAIN PUMP STOP LEVEL SWITCH (TRIPP)
C161	WATER/OIL SEPARATOR MAIN PUMP START LEVEL SWITCH
C160	WATER/OIL SEPARATOR MAIN PUMP STOP LEVEL SWITCH
C89	WATER/OIL SEPARATOR MAIN PUMP STOP LEVEL SWITCH
C88	WATER/OIL SEPARATOR SPARE PUMP STOP LEVEL SWITCH
C97	PRESSURE ON BRAKE PRESSURE SWITCH
C96	DRAINAGE VERY HIGH WATER LEVEL SWITCH (TRIPP)
C96	DRAINAGE HIGH WATER LEVEL SWITCH (ALARM)
C93	DRAINAGE MAIN PUMP START LEVEL SWITCH
C92	DRAINAGE MAIN PUMP STOP LEVEL SWITCH
C91	TURBINE DRAINAGE SPARE PUMP START LEVEL SWITCH
C90	TURBINE DRAINAGE SPARE PUMP STOP LEVEL SWITCH
C85	VERY HIGH TURBINE BEARING TEMPERATURE SWITCH
C84	HIGHT TURBINE BEARING TEMPERATURE SWITCH
C83	LUBRICATION COOL SYSTEM TEMPERATURE SWITCH
C82	LUBRICATION SYSTEM LOW OIL LEVEL SWITCH
C81	LUBRICATION SYSTEM VERY HIGH OIL TEMPERATURE SWITCH
C80	LUBRICATION COOL SYSTEM OIL TEMPERATURE SWITCH
C77	VERY LOW SHAFT SEAL WATER PRESSURE SWITCH
C76	LOW SHAFT SEAL WATER PRESSURE SWITCH
C75	TURBINE BEARING OIL FLOW SWITCH
C74	LUBRICATION OIL FILTER CLOGGED PRESSURE SWITCH
C73	LUBRICATION OIL FILTER CLOGGED PRESSURE SWITCH
C72	OIL IN WATER PROBE
C70	TURBINE BEARING OIL PRESSURE SWITCH
C60	GOVERNING SYSTEM OIL TANK HIGH TEMPERATURE SWITCH
C50	GOVERNING SYSTEM OIL TANK LOW OIL LEVEL SWITCH
C49	RUNNER BLADES OIL FILTER CLOGGED PRESSURE SWITCH
C48	RUNNER BLADES OIL FILTER CLOGGED PRESSURE SWITCH
C47	WCKET GATES OIL FILTER CLOGGED PRESSURE SWITCH
C46	WCKET GATES OIL FILTER CLOGGED PRESSURE SWITCH
C45	RUNNER BLADES HIGH OIL PRESSURE PRESSURE SWITCH
C44	RUNNER BLADES HIGH OIL PRESSURE PRESSURE SWITCH
C43	RUNNER BLADES LOW OIL PRESSURE PRESSURE SWITCH
C42	WCKET GATES LOW OIL PRESSURE PRESSURE SWITCH - START SPARE PUMP
C41	WCKET GATES LOW OIL PRESSURE PRESSURE SWITCH - START SPARE PUMP
C40	WCKET GATES LOW OIL PRESSURE PRESSURE SWITCH
C39	RUNNER BLADES CIRCUIT ACCUMULATOR ISOLATION VALVE CLOSED SWITCH
C38	WCKET GATES CIRCUIT ACCUMULATOR ISOLATION VALVE CLOSED SWITCH
C37	RUNNER BLADES LOW OIL RUNNING POSITION SWITCH
C36	RUNNER BLADES LOW OIL RUNNING POSITION SWITCH
C35	WCKET GATES FULL OPEN POSITION SWITCH
C34	WCKET GATES FULL OPEN POSITION SWITCH
C33	WCKET GATES LOW OIL RUNNING POSITION SWITCH
C32	WCKET GATES LOW OIL RUNNING POSITION SWITCH
C31	WCKET GATES LOW OIL RUNNING POSITION SWITCH
C30	WCKET GATES LOW OIL RUNNING POSITION SWITCH
B5	TURBINE SHIP SEAL TEMPERATURE PROBE
B4	TURBINE SHIP SEAL TEMPERATURE PROBE
B3	SPEED DETECTOR
B2	RUNNER BLADES POSITION TRANSDUCER
B1	WCKET GATES POSITION TRANSDUCER
A10	LUBRICATION SYSTEM OIL TANK THERMOELECTRIC HEATER
A9	GOVERNING SYSTEM OIL TANK THERMOELECTRIC HEATER
A1	Reference



AQUATIS a.s. Tel: +420 541 554 111 E-mail: info@aquatis.cz
Botanická 834/56, 602 00 Brno Fax: +420 541 211 205 <http://www.aquatis.cz>

Zodpovědný projektant ING. MILOSLAV KUPSKÝ	Hlavní inženýr projektu ING. OLDŘICH NEUMAYER CSc.	Vedoucí střediska ING. OLDŘICH NEUMAYER CSc.
---	---	---

Vypracoval ING. MILOSLAV KUPSKÝ	Kontroloval ING. TOMAŠ ROTH	Zakázkové číslo 025009A
------------------------------------	--------------------------------	----------------------------

Datum ČERVEN, 2025	Stupeň dokumentace DVZ	Název souboru D21215 Schema R.dwg
-----------------------	---------------------------	--------------------------------------

Akce
MVE VRAŇANY - REKONSTRUKCE TECHNICKÉ ČÁSTI

D.2. TECHNOLOGICKÁ ČÁST

PS 01 TECHNOLOGICKÁ ČÁST STROJNÍ

D.2.1.2. VÝKRESOVÁ ČÁST

Priloha SCHEMA REGULACE

SCHEMA REGULACE	
Měřítka	Číslo přílohy

1 : 100

Objednatel
Ředitel Vltavy, státní podnik

1. Úvodní věty, stručný podnět