

Technical data Actuator controls

General information

ACV 01.2 actuator controls for controlling actuators with variable speed or operating times of the SAV/SARV .2 and SQV/SQRV .2 type range .

Features and functions

Power supply	Standard voltages AC:									
	3-phase AC					1-phase AC				
	Voltages/frequencies					Voltages/frequencies				
	Volt	220 – 240		380 – 480		Volt	110 – 120		220 – 240	
	Hz	50	60	50	60	Hz	50	60	50	60
	Permissible variation of mains frequency: ±5 %									
	Permissible variation of mains voltage: ±10 %									
	–30 % for maximum 10 seconds within a range of 380 V – 480 V with the following restrictions:									
	<ul style="list-style-type: none">• If required, the motor speed will be reduced down to nominal speed depending on the load of the actuators used• A low mains voltage increases the mains current consumption; a higher mains voltage reduces the mains current consumption• The torque limits of the actuators used might be decreased for a short time, if applicable									
	External supply of the electronics (option)	24 V DC: +20 % / –15 % Current consumption: Basic version approx. 250 mA, with options up to 500 mA For external electronics supply, the power supply of integral controls must have an enhanced isolation against mains voltage in compliance with IEC 61010-1 and the output power be limited to 150 VA.								
Rated power	Actuator controls are designed for nominal motor power, refer to Electrical data pertaining to the actuator									
Control inputs	6 digital inputs: OPEN, STOP, CLOSE, EMERGENCY (via opto-isolator, thereof OPEN, STOP, CLOSE with one common and EMERGENCY without common, respect minimum pulse duration for modulating actuators.									
Control voltage/current consumption for control inputs	Standard	24 V DC, current consumption: approx. 10 mA per input								
	Options:	48 V DC, current consumption: approx. 7 mA per input								
		60 V DC, current consumption: approx. 9 mA per input								
		100 – 125 V DC, current consumption: approx. 15 mA per input								
		100 – 120 V AC, current consumption : approx. 15 mA per input								
	All input signals must be supplied with the same potential.									

Technical data Actuator controls

Features and functions		
Status signals (output signals)	Standard:	<ul style="list-style-type: none"> 6 programmable output contacts: <ul style="list-style-type: none"> 5 potential-free NO contacts with one common, max. 250 V AC, 1 A (resistive load) Default configuration: End position CLOSED, end position OPEN, selector switch REMOTE, torque fault CLOSE, torque fault OPEN 1 potential-free change-over contact, max. 250 V AC, 5 A (resistive load) Default configuration: Collective fault signal (torque fault, phase failure, motor protection tripped) Analogue output signal for position feedback <ul style="list-style-type: none"> Galvanically isolated position feedback 0/4 – 20 mA (load max. 500 Ω)
	Options:	<ul style="list-style-type: none"> 6 programmable output contacts: <ul style="list-style-type: none"> 5 change-over contacts with one common, max. 250 V AC, 1 A (resistive load), 1 potential-free change-over contact, max. 250 V AC, 5 A (resistive load) 12 programmable output contacts: <ul style="list-style-type: none"> 10 potential-free NO contacts, 5 with one common each, max. 250 V AC, 1 A (resistive load), 2 potential-free change-over contacts, max. 250 V AC, 5 A (resistive load) 6 programmable output contacts: <ul style="list-style-type: none"> 6 potential-free change-over contacts without one common, per contact max. 250 V AC, 5 A (resistive load) 10 programmable output contacts: <ul style="list-style-type: none"> 10 potential-free change-over contacts without one common, per contact max. 250 V AC, 5 A (resistive load) 6 programmable output contacts: <ul style="list-style-type: none"> 4 mains failure proof potential-free NO contacts with one common, max. 250 V AC, 1 A (resistive load), 1 potential-free NO contact, max. 250 V AC, 1 A (resistive load), 1 potential-free change-over contact, max. 250 V AC, 5 A (resistive load) 6 programmable output contacts: <ul style="list-style-type: none"> 4 mains failure proof potential-free NO contacts, max. 250 V AC, 5 A (resistive load), 2 potential-free change-over contacts, max. 250 V AC, 5 A (resistive load), 12 programmable output contacts: <ul style="list-style-type: none"> 8 mains failure proof potential-free NO contacts, max. 250 V AC, 1 A (resistive load), 2 potential-free NO contacts, max. 250 V AC, 1 A (resistive load), 2 potential-free change-over contacts, max. 250 V AC, 5 A (resistive load) 12 programmable output contacts: <ul style="list-style-type: none"> 8 mains failure proof potential-free NO contacts, max. 250 V AC, 5 A (resistive load), 4 potential-free change-over contacts, max. 250 V AC, 5 A (resistive load), <p>All output signals must be supplied with the same potential.</p>
Voltage output	Standard:	Auxiliary voltage 24 V DC: max. 100 mA for supply of control inputs, galvanically isolated from internal voltage supply.
	Option:	Auxiliary voltage 115 V AC: max. 30 mA for supply of control inputs, galvanically isolated from internal voltage supply (Not possible in combination with PTC tripping device)
Analogue output	Standard:	2 analogue outputs: With position transmitter option: Output of travel, torque or output speed as continuous values between 0/4 and 20 mA
Analogue input	Option:	2 analogue inputs: With positioner/process controller option: Input of actual position value/actual process value as continuous values of 0/4 – 20 mA
Local controls	Standard:	<ul style="list-style-type: none"> Selector switch: LOCAL - OFF - REMOTE (lockable in all three positions) Push buttons: OPEN, STOP, CLOSE, RESET <ul style="list-style-type: none"> Local STOP The actuator can be stopped via push button STOP of local controls if the selector switch is in position REMOTE. 6 indication lights: <ul style="list-style-type: none"> End position and running indication CLOSED (yellow), torque fault CLOSE (red), motor protection tripped (red), torque fault OPEN (red), end position and running indication OPEN (green), Bluetooth (blue) Graphic LC display: illuminated
	Option:	<ul style="list-style-type: none"> Special colours for the indication lights: <ul style="list-style-type: none"> End position CLOSED (green), torque fault CLOSE (blue), torque fault OPEN (yellow), motor protection tripped (violet), end position OPEN (red)

Technical data Actuator controls

Features and functions		
Bluetooth Communication interface	Bluetooth class II chip, version 2.1: With a range up to 10 m in industrial environments; supports the SSP Bluetooth profile (Serial Port Profile). Required accessories: <ul style="list-style-type: none"> AUMA CDT (Commissioning and Diagnostic Tool for Windows-based PC) AUMA Assistant App (Commissioning and Diagnostic Tool) 	
Application functions	Standard:	<ul style="list-style-type: none"> Selectable type of seating, limit or torque seating for end position OPEN and end position CLOSED Torque by-pass: Adjustable duration (with adjustable peak torque during start-up time) Start and end of stepping mode as well as ON and OFF times can be set individually for directions OPEN and CLOSE, 1 to 1,800 seconds Operation profile with any 8 intermediate positions: Position can be set between 0 and 100 %, reaction and signal behaviour programmable Velocity profile with up to 10 ranges, velocity can be individually adjusted for positions OPEN and CLOSED for each range Running indication blinking: can be set Speed/operating time source can be selected (REMOTE, LOCAL) 4 internal nominal speeds or operating times can be programmed (and selected in LOCAL) Nominal speed source/nominal operating time source can be selected for REMOTE (binary, analogue) Soft start, soft stop with velocity reduction (adjustable)
	Options:	<ul style="list-style-type: none"> Positioner: <ul style="list-style-type: none"> Position setpoint via analogue inputs 0/4 – 20 mA Programmable behaviour on loss of signal Automatic adaptation of dead band (adaptive behaviour selectable) Split range operation MODE input for selecting between OPEN-CLOSE and setpoint control Modulating duty with proportional operation (2 % – 20 %) PID process controller: with adaptive positioner, via 0/4 – 20 mA analogue inputs for process setpoint and actual process value Multiport valve: Up to 16 positions, signals (pulse or edge) (SAV/SARV .2 only) Lift Plug Valve: In combination with multiport valve (SAV/SARV. 2 only) Automatic deblocking: Up to 5 operation trials, travel time in opposite direction can be set Static and dynamic torque recording for both rotation directions with torque measurement flange as additional accessory
Safety functions	Standard:	<ul style="list-style-type: none"> EMERGENCY operation (programmable behaviour) <ul style="list-style-type: none"> Digital input: Low active Reaction can be selected: STOP, run to end position (OPEN, CLOSED) or intermediate position at defined speed Torque monitoring can be by-passed during EMERGENCY operation Thermal protection can be by-passed during EMERGENCY operation (only in combination with thermoswitch within actuator, not with PTC thermistor).
	Options:	<ul style="list-style-type: none"> Enabling local controls via Enable LOCAL digital input: Thus, actuator operation can be enabled or disabled via push buttons on the local controls. Interlock for main/by-pass valve: Enabling the operation commands OPEN or CLOSE via two digital inputs EMERGENCY Stop push button (latching): Interrupts electrical operation, irrespective of the selector switch position PVST (Partial Valve Stroke Test): programmable to check the function of both actuator and actuator controls: Direction, stroke, operation time, reversing time
Monitoring function	<ul style="list-style-type: none"> Valve overload protection: Adjustable, results in switching off and generates fault signal Motor temperature monitoring (thermal monitoring): Results in switching off and generates fault signal Monitoring the heater within actuator: Generates warning signal Monitoring of permissible on-time and number of starts: Adjustable, generates warning signal Operating time monitoring: Adjustable, generates warning signal Phase failure monitoring: Results in switching off and generates fault signal 	

Technical data Actuator controls

Features and functions		
Diagnostic functions	<ul style="list-style-type: none"> Electronic device ID with order and product data Operating data logging: A resettable counter and a lifetime counter each for: <ul style="list-style-type: none"> Motor running time, number of starts, torque switch trippings in end position CLOSED, limit switch trippings in end position CLOSED, torque switch trippings in end position OPEN, limit switch trippings in end position OPEN, torque faults CLOSE, torque faults OPEN, motor protection trippings Time-stamped event report with history for setting, operation and faults: <ul style="list-style-type: none"> Status signals according to NAMUR recommendation NE 107: "Failure", "Function check", "Out of specification", "Maintenance required" Torque characteristics (for version with MWG in actuator): <ul style="list-style-type: none"> 3 torque characteristics (torque-travel characteristic) for opening and closing directions can be saved separately Torque characteristics stored can be shown on the display. 	
Motor protection evaluation	Standard:	Monitoring the motor temperature in combination with thermoswitches within actuator motor
	Option:	PTC tripping device (TMS module) in combination with PTC thermistors within actuator motor
ACV 01.2 heating system (option)	<p>Temperature version below –30 °C including heating system:</p> <ul style="list-style-type: none"> in version with internal power supply at 400 V AC, or in version with external power supply for 230 V AC or 115 V AC <p>For external power supply of the heating system, the minimum operational temperature may not fall below –40 °C in case of danger of disconnection of the mains voltage.</p>	
Electrical connection	Standard:	AUMA plug/socket connector with screw-type connection
	Options:	<ul style="list-style-type: none"> Terminals or crimp connection Gold-plated control contacts (pins and sockets)
Threads for cable entries	Standard:	Metric threads
	Options:	Pg-threads, NPT-threads, G-threads

For version with MWG within actuator

Setting of limit and torque switching via local controls	
Torque feedback signal	Galvanically isolated analogue output 0/4 – 20 mA (load max. 500 Ω).
Wiring diagram (basic version)	TPCH-0A1-1AF-A000 TPA00R100-0I1-000, 3-phase AC current; 380 V – 480 V TPCH-0A1-1AE-A000 TPA00R100-0I1-000, 1-phase AC current; 220 V – 240 V

Service conditions		
Use	Indoor and outdoor use permissible	
Mounting position	Any position	
Installation altitude	≤ 2 000 m above sea level > 2,000 m above sea level on request	
Ambient temperature	Standard:	–30 °C to +70 °C
	Options:	–40 °C to +70 °C –60 °C to +60 °C, extreme low temperature version Low temperature versions including heating system. For further options, refer to line "ACV 01.2 heating system (option)".
Humidity	Up to 100 % relative humidity across the entire permissible temperature range	
Enclosure protection in accordance with IEC 60529	Standard:	IP68
	Option:	DS terminal compartment additionally sealed against interior of actuator controls (double sealed)
According to AUMA definition, enclosure protection IP68 meets the following requirements: <ul style="list-style-type: none"> Depth of water: maximum 8 m head of water Continuous immersion in water: maximal 96 hours Up to 10 operations during immersion Modulating duty is not possible during immersion. 		
Pollution degree according to IEC 60664-1	Pollution degree 4 (when closed), pollution degree 2 (internal)	

Technical data Actuator controls

Service conditions	
Vibration resistance according to IEC 60068-2-6	1 g, from 10 Hz to 200 Hz Resistant to vibration during start-up or for failures of the plant. However, a fatigue strength may not be derived from this. Not valid in combination with gearboxes.
Corrosion protection	Standard: KS: Suitable for use in areas with high salinity, almost permanent condensation, and high pollution.
	Option: KX: Suitable for use in areas with extremely high salinity, permanent condensation, and high pollution.
Coating	Double layer powder coating Two-component iron-mica combination
Colour	Standard: AUMA silver-grey (similar to RAL 7037)
	Option: Available colours on request
Accessories	
Wall bracket	For actuator controls mounted separately from the actuator, including plug/socket connector. Connecting cable on request. Recommended for high ambient temperatures, difficult access, or in case of heavy vibration during service. Cable length between actuator and actuator controls is max. 16 m.
Programming software	AUMA CDT (Commissioning and Diagnostic Tool for Windows-based PC) AUMA Assistant App (Commissioning and Diagnostic Tool)
Torque measurement flange DMF (SAV/SARV .2 only)	Accessory for torque measurement
Further information	
Weight	Approx. 7 kg (with AUMA plug/socket connector)
EU Directives	Machinery Directive 2006/42/EC Low Voltage Directive 2014/35/EU EMC Directive 2014/30/EU RoHS Directive 2011/65/EU RED Directive 2014/53/EU
Reference documents	Dimensions SAV 07.2 – SAV 16.2/SARV 07.2 – SARV 16.2 with ACV 01.2 Dimensions SQV 05.2 – SQV 14.2/SQVR 05.2 – SQVR 14.2 with ACV 01.2 Electrical data SAV 07.2 – SAV 16.2/SARV 07.2 – SARV 16.2 Electrical data SQV 05.2 – SQV 14.2/SQVR 05.2 – SQVR 14.2